




使用说明书

闪光灯遥控器



感谢您选购本产品!

为充分发挥其性能并确保安全使用, 请在使用前仔细阅读本说明书。

如果您在使用过程中遇到任何问题, 您可以联系当地经销商或官方渠道。

相关产品使用指南或常见问题, 也可以通过官网、微信公众号或facebook获取相应信息。



www.funmount.com




wechat



facebook

- 01 -

一、按键指示



①小按键 ③电源开关

②大按键 ④电池仓

- 02 -

二、按键功能

- 电源开关:**
on接通电源, off切断电源
- 小按键:**
长按3秒进入配对模式, 此时闪光灯也设置进入配对模式, 两者会自动配对。
- 大按键:**
a. 连上闪光灯情况下, 单击大按键远程触发闪光灯;
b. 仅连接手机的情况下, 单击触发手机拍照。
- 小按键+大按键:**
组合键长按3秒, 清除所有连接绑定信息。

三、灯光指示


- 常亮: 已连接闪光灯。
- 间隔一秒闪烁: 未连接上闪光灯。
- 间隔0.6秒闪烁: 进入闪光灯配对。
- 短时间高频闪烁: 成功清除全部配对信息。

- 03 -



User Manual

Flash Remote Control



Thank you for purchasing this product! To fully utilize its performance and ensure safe use, please read this instruction manual carefully before use.

If you encounter any problems during use, you can contact local dealer or official channels. For related product usage guides or FAQs, you can also be obtained through the official website, WeChat public account or Facebook as below .



www.funmount.com




wechat



facebook

- 01 -

I. Button Indicators



①Small Button ③Power Switch

②Large Button ④Battery Compartment

- 02 -

II. Button Functions

- Power Switch:**
ON: Powers on the device; OFF: Powers off the device.
- Small Button:**
Long-press for 3 seconds to enter pairing mode; set the flash to pairing mode as well, and the two will pair automatically.
- Large Button:**
a. When connected to a flash: Single-press to trigger the flash remotely.
b. When connected only to a mobile phone: Single-press to trigger the phone's camera shutter.
- Small Button + Large Button:**
a. Long-press both buttons simultaneously for 3 seconds to clear all pairing/binding information.

III. Light Indicators

- Solid light: Connected to the flash.
- Flashing at 1-second intervals: Not connected to the flash.
- Flashing at 0.6-second intervals: Entering flash pairing mode.
- Rapid flashing (short burst): Pairing information successfully cleared.

- 03 -